


4LC-180L-B5

Mounting diagram