


4LC-315L-4-8P-B5
Mounting diagram